

Heat Press Settings / Instructions

Hotronix 360 IQ Hat Press




Home Screen

Status bar provides helpful information regarding heat press.

Touch and edit your favorite presets.

Lock the screen (Manager-level only) to prevent User-level operators from changing settings.

Touch and edit Users to control operator access level and track press usage by operator in the IQ® Portal.



3.1

Touch Setup Menu.

Place press in Standby Mode to take advantage of the scheduled Auto On feature.

Displays current top heater temperature.

Displays current bottom heater temperature.

Displays current application pressure and time.

IQ® Portal and WIFI connection status.

360 IQ HAT PRESS OPERATORS MANUAL.pdf

SETTINGS / INSTRUCTIONS	Top Bottom Temp (°F)	Pressure	Warm-Up (sec)	Time (sec)	1/8" Foam Pad	Peel Backing	Additional Time (sec)
Embroidered	280 320	8		20-50	X		
Leather	280 320	6		25	X		
E, W, D	280 320	7		25	X		
HTV / DTF	320 25			20			
Supacolor	300 30	8	3	10		X	3
Supacolor (alternate)	290 32	10	3	12		X	2

